



TON CONTAINER ADAPTERS

-INNOVATION & QUALITY-

Ton container adapters are used to adapt any standard cylinder-mounted vacuum regulator for use on a standard one-ton container. Archer Instruments offers two types of ton container adapters.

Pictured to the right is the TCA-IRON ton container adapter. This adapter is assembled using epoxy-coated extra-heavy seamless black iron pipe fittings. These are the industry standard fittings used to construct pressurized chlorine manifolds.

It is to be expected that the inside of this adapter will, over time require occasional disassembly and cleaning.

Pictured to the right is the TCA-MONEL ton container adapter. This adapter is constructed of silicon-bronze alloys and pipe fittings made of Monel. These choice materials are highly resistant to chlorine and will ensure a cleaner functionality over longer periods of use.

All Archer Instruments ton container adapters are equipped with a full-containment, powder-coated yoke assembly as recommended by The Chlorine Institute. Both adapters are also supplied with a pre-curved drip leg heater & a six-foot (2 meter) long power chord.

Either adapter can be supplied for "left-hand" orientation upon request.



Shown above: TCA-IRON



Shown above: TCA-MONEL